# Adelphi Manufacturing



The Adelphi Accuramatic Pump Dispenser and Adelphi XYZ Distributor - Filling for mobile liquids and light oils



The XYZ Distributor is used in conjunction with the Adelphi Accuramatic Pump Dispenser, which allows bottles and vials to be filled automatically in trays. The Z axis is the diving nozzle movement that allows liquid to be automatically filled from above the neck or into the neck.

- Control box remote from moving nozzle frame suitable for use in lamina flow cabinet.
- Adjustable trays are supplied so that bottles are held in an orderly fashion.
- Setting up is easy using the menu-driven LCD displays.
- Special trays can be made to suit odd shaped bottles.
- Fills straight rows or honeycombed configurations.

## Adelphi XYZ Distributor

Services Required Electricity (selectable) **Specifications** Movement Space Electronics Weight Dimensions Distribution 790 x 625 x 390mm Control Dimensions Drip Delay Max Vial Height (mm) Min Neck Opening Tray

220-240 / VAC single phase

X=520 Y=335 Z=155mm Microprocessor Control 4.5kg XYZ 9.0kg 200 x 280 x 180mm 0.0 - 0.9 secs 200 8mm 410 x 265mm fill area



Adelphi Manufacturing **Olympus House** Mill Green Road Haywards Heath, West Sussex RH16 1XQ, UK

T: +44 (0)1444 472300 sales@adelphi.uk.com

F: +44 (0)1444 472329 www.adelphi.uk.com

# Adelphi Manufacturing

# Adelphi Accuramatic



## Adelphi Accuramatic

#### S pecifications Volumes Repeatability Max flow rate

Services required

1ml to 1,000ml ±0.5% 36ml/sec (standard pump, twin pump option available, see chart) 230 VAC, 50 Hz standard 50 watts nett 8.5kg gross 10.5kg 44 x 23 x 43cm

### Features

- Stainless steel case
- Sealed membrane keypad and digital display
- Pump pulse compensated for greater accuracy
- 3 filling modes braked stop
  - soft stop
    - suck back after brake stop

Adelphi Manufacturing

Filling & Packaging Machinery

- Pump can rotate backwards or forwards
- Timed filling up to 99.99 seconds with delays between fills up to 99.99 seconds
- RS232 interface allows data to be incorporated from PC
- Choice of 1.6mm or 2mm wall pump head to suit either wall thickness of tube
- Completely closed filling system eliminating cross contamination

### Description

The machine can be operated by hand, footswtich or will cycle automatically with a delay of up to 9.9 seconds between fills. The liquid only comes into contact with one uninterrupted length of silicone tubing which will withstand repeated sterilisation. The peristaltic pump is controlled to run at constant speed for a precisely determined period. The basic machine comes with a two-roller pump, footswitch and two metre lengths of five sizes of silicone tubing (see chart). A double pump is also available for larger outputs or for filling two products at the same time.

#### 2mm Wall Tube Sizes

Typical Volume (ml)	Tubing Bore (mm)	Delivery Rate (ml/sec)
0.2-5	Twin Microbore	1
5-15	2.4	4
15-50	4	10
50-100	6	24
100+	8	36



Weight

Carton size

Adelphi Manufacturing Olympus House Mill Green Road Haywards Heath, West Sussex RH16 1XQ, UK

T: +44 (0)1444 472300 sales@adelphi.uk.com